


## Installation Guide

### Step 1: Unpack Projector

1. Remove one projector and one installation kit box.
2. Open the protective projector bag and remove the projector.
3. Open the installation box and remove the mounting bracket, retaining ring and cloth from plastic pouch in the box and power supply.



### Step 2: Insert or Change Gobo

- A Un-thread the lens of the projector to expose the gobo placement area.
- B Insert the gobo into the projector backwards and upside-down of the desired orientation. If dust is noticed, use provided micro cloth to gently wipe off the optics and gobo.
- C Insert the retention ring on top of the gobo to secure gobo in place.
- D Thread the lens onto the projector.

### Step 3: Mount Projector

- A Use the included bracket mount or any standard 1/4" 20 mounting option to mount projector.
- B Place projector into bracket. By rotating the bracket and projector, aim projected image to desired location, then secure by tightening thumb screw.
- C Focus gobo by rotating lens.
- D To adjust the size of the gobo, move the unit closer to or further away from the desired location and adjust the focus accordingly. **\*\*Do not plug into a dimmed circuit.**

